

Up/Down Counter/Timer

DIN size W72×H36mm, Indication only Counter/Timer

■ Features

- Upgraded count speed : 5kps
- Wide range of input power supply :
100~240VAC 50/60Hz, 12~24VDC (Option)
- Microprocessor controlled
- Selectable Counter or Timer function by internal DIP switch
- Selectable timing ranges



Please read "Caution for your safety" in operation manual before using.



(A)
Counter

(B)
Timer

(C)
Temp.
controller

(D)
Power
controller

(E)
Panel
meter

(F)
Tacho/
Speed/
Pulse
meter

(G)
Display
unit

(H)
Sensor
controller

(I)
Proximity
sensor


(J)
Photo
electric
sensor

(K)
Pressure
sensor

(L)
Rotary
encoder

(M)
5-Phase
stepping
motor &
Driver &
Controller

■ Ordering information




■ Specifications

* A blacked(□) item is upgraded function.

Model	FX4Y-I		FX6Y-I		
Digit	4		6		
Digit size	W8×H14mm		W4×H8mm		
Power supply	100~240VAC 50/60Hz, 12~24VDC (Option)				
Allowable voltage range	90 ~ 110% of rated voltage				
Power consumption	Approx. 4.5VA (240VAC 60Hz), Approx. 2.5W (24VDC)				
Max. counting speed	Selectable 30cps/5kcps by internal DIP switch				
Min. input signal width	INHIBIT input		Min. 20ms		
	RESET input				
Input	CP1, CP2 input	No voltage input [※] Impedance at short-circuit : Max. 470Ω, Residual voltage at short-circuit : Max. 1VDC, Impedance at open-circuit : Min. 100kΩ			
	RESET input				
Memory retention	10years (When using non-volatile semiconductor memory)				
Power for external sensor	12VDC±10% 50mA Max.				
Insulation resistance	Min. 100MΩ (at 500VDC)				
Dielectric strength	2000VAC 50/60Hz for 1 minute				
Noise strength	AC Type	±2kV the square wave noise (pulse width:1μs) by the noise simulator			
	DC Type	±500V the square wave noise (pulse width:1μs) by the noise simulator			
Vibration	Mechanical	0.75mm amplitude at frequency of 10 ~ 55Hz in each of X, Y, Z directions for 1hour			
	Malfunction	0.5mm amplitude at frequency of 10 ~ 55Hz in each of X, Y, Z directions for 10 minutes			
Shock	Mechanical	300m/s ² (Approx. 30G) in X, Y, Z directions for 3 times			
	Malfunction	100m/s ² (Approx. 10G) in X, Y, Z directions for 3 times			
Ambient temperature	-10 ~ +55°C (at non-freezing status)				
Storage temperature	-25 ~ +65°C (at non-freezing status)				
Ambient humidity	35 ~ 85%RH				
Life cycle	semi-permanent				
Weight	AC type: Approx. 126g, DC type: Approx. 130g AC type: Approx. 128g, DC type: Approx. 132g				
Approval					

FXY Series

Connections



(※1)It can be selected reset or sensor power(+12VDC 50mA) by controlling internal jump pin.

(※2)CP1, CP2 : When using for counter


(※3)INHIBIT(CP2) : Time Hold terminal when using for timer(Connect S/W to ②+④ in exterior)

(※4)Operated by a Power ON Start method when it is used as a timer.

Input connections

◎Solid-state input


- Standard input sensor : NPN universal output type sensor




- Transistor ON → Counting
- NPN universal output type sensor

*CP1, CP2(INHIBIT), RESET input

◎Contact input




- Transistor ON → Counting
- NPN open collector output type sensor



- Contact ON → Counting
- Limit S/W, Micro S/W
- Please use a reliable contacts


- Using PNP universal output type sensor



- Since PNP universal output type of sensors has high output impedance, please make sure to keep under condition.
: Please set R1 value to make the composed resistance of RL + R1 is Max. 470kΩ

*CP1, CP2(INHIBIT), RESET input

- Using PNP open collector output type sensor



- In case of PNP open collector output type sensor, please connect lower than 470Ω of R1 to input terminal before using.



Up/Down Counter/Timer

◎Counting method

Please take care of the selection of sensor because the counting method of NPN output type sensor is different from PNP output type sensor.



●NPN universal output type

: When the sensor changes OFF to ON, it is counting



●PNP universal output type

: When the sensor changes ON to OFF, it is counting



(A)
Counter

(B)
Timer

(C)
Temp.
controller

(D)
Power
controller

(E)
Panel
meter

(F)
Tacho/
Speed/
Pulse
meter

(G)
Display
unit

(H)
Sensor
controller

(I)
Proximity
sensor



(J)
Photo
electric
sensor

(K)
Pressure
sensor


(L)
Rotary
encoder

(M)
5-Phase
stepping
motor &
Driver &
Controller

□Dimensions




●Panel cut-out




Unit:mm

□Counting function


●Up mode




●Down mode



●Up/Down-A, B, C Mode





●Up/Down-D, E, F Mode



FXY Series

■ Selection by DIP switches



● Up/Down mode

SW1	Function
4	Up mode
	Down mode

● Max. counting speed

SW1	CP1, CP2
5	30cps
	5kcps

● Manual reset selection

SW1	Function
6	Reset switch disabled
	Reset switch enabled

● Memory retention

SW1	Function
7	Memory
	Power reset(No memory)

● Counter/Timer selection

SW1	Function
8	Timer
	Counter

■ Time setting mode(Timer)

SW1	4Digit	6Digit	SW1	4Digit	6Digit
A 	99.99sec	99999.9sec	E 	999.9min	99999.9min
B 	999.9sec	999999sec	F 	99hour 59min	99hour 59min 59sec
C 	9999sec	99min 59.99sec	G 	999.9hour	9999hour 59min
D 	99min 59sec	999min 59.9sec	H 	9999hour	99999.9hour

Up/Down Counter/Timer

Input mode(Counter)

Input mode(SW1)		Up mode	Input mode(SW1)		Down mode
Up/Down-A Command input	OFF 2 3 ON	<p>CP1 H L</p> <p>Counting value</p>	Up/Down-D Command input	OFF 2 3 ON	<p>CP1 H L</p> <p>Counting value</p>
Up/Down-B Individual input	OFF 2 3 ON	<p>CP1 H L</p> <p>Counting value</p>	Up/Down-B Individual input	OFF 2 3 ON	<p>CP1 H L</p> <p>Counting value</p>
Up/Down-C Phase difference input	OFF 2 3 ON	<p>CP1 H L</p> <p>Counting value</p>	Up/Down-F Phase difference input	OFF 2 3 ON	<p>CP1 H L</p> <p>Counting value</p>
Up input	OFF 2 3 ON	<p>CP1 H L</p> <p>Counting value</p>	Down input	OFF 2 3 ON	<p>CP1 H L</p> <p>Counting value</p>
	OFF 2 3 ON	<p>CP1 H L</p> <p>Counting value</p>		OFF 2 3 ON	<p>CP1 H L</p> <p>Counting value</p>

*Ⓐ: Over Min. signal width, Ⓑ: Over 1/2 of Min. signal width.

Counting miss by one(±) is occurred if the signal width of Ⓑ or Ⓒ is less than Min. signal width.

*n : + Max.display value(FX4Y-I : 9999, FX6Y-I : 999999)

- (A) Counter
- (B) Timer
- (C) Temp. controller
- (D) Power controller
- (E) Panel meter
- (F) Tacho/ Speed/ Pulse meter
- (G) Display unit
- (H) Sensor controller
- (I) Proximity sensor
- (J) Photo electric sensor
- (K) Pressure sensor
- (L) Rotary encoder
- (M) 5-Phase stepping motor & Driver & Controller

FXY Series

Proper usage

Reset


● Reset

When select a reset input/output mode again, after applying power, please reset or reset manually.

Otherwise it previous mode will be operating.

● The reset signal width


It is reset perfectly when the reset signal is applied for **max. 20ms** regardless of the contact input & solid-state input.



*In case of a contact reset, it is reset perfectly if the ON time of reset signal is applied for max. 20ms even though a chattering is occurred.

**Signal input(Cp1, Cp2) is possible if there is no reset input for min. 50ms after reset input.


Min.signal width



Maximum counting speed


This is respond speed per 1 sec. when the duty rate (ON/OFF) of input signal is 1:1 if duty rate is not 1:1, the respond speed will be getting slow against input signal and also the width between ON and OFF should be over min. signal width.

And one of ON width and OFF width is under min. signal width, this product may not response.




Detach the case from body


While pushing the lock equipment with driver to the way of front, push the terminal block.




Using inner pin




When using terminal 3 for external reset terminal




When using terminal 3 for sensor power terminal



INHIBIT Only timer



- It becomes the INHIBIT mode when SW1 turns on. (Time Hold)
- In case of stopping time at a moment while the timer is progressing, the Inhibit mode can be used.
- When the Inhibit input is cut off, time is progressing again.



Power

The inner circuit voltage starts to rise up for the first 100ms after power on, the input may not work at this time. And also the inner circuit voltage drops down for the last 500ms after power off, the input may not work at this time.

